

SLOTWALL INSTALLATION GUIDE

1. Lift **SlotWall** off the stack. Do not slide. Sliding may cause damage to the surface. Be careful of all edges and corners as they are easily damaged. Always use two or more people when handling.
2. The backside of the panel should be used for marking and cutting. This reduces abrasions to the finished surface and provides for a totally flat surface.
3. Use a level to ensure that a panel is installed in a level horizontal position.
4. Pre-drill holes for the screws according to screw size.
5. Don't over tighten the screws.
6. The screws should go into a solid structure such as a stud.
7. Where cement blocks are used, it is recommended that furring strips be attached to the Blocks. This will allow space to insert insulation behind the finished wall. Additional support may be obtained by using panel adhesive.
8. Drill a screw into every stud horizontally and into every 5th slot vertically for Maximum hold.
9. Mount the bottom panel first. Each panel has a projecting lip to provide proper slot Spacing for the panels to be inserted to each other.
10. Install all the channel supports into the panel before mounting the panel to the wall.

Recommended tools: Drill, Phillips Head Drill Bit, 2" Flathead Drywall Screws, Level, Tape Measure and Safety Glasses.